




WARNING


1. Switch off before installation/ maintenance
2. Switch on only after complete installation and examination of the circuit.
3. Professional electrician for installation and maintenance only.



Turn Off
Power Supply

How to install





4



5

Button Function Instruction

STATUS

					ON
					OFF

Light Sensor

PIR Sensor

Turn ON/OFF

DIM

Sensor

0% 100%

x1

x2

x3